


Bagger Coupler to excavators



All are CE-marked!
Weight - approximately!



A complete programme for hydraulic and mechanical quick-couplers.

All types are automatic adjusted and available with mechanical and hydraulic locking.

The quick-coupler [grind] allows buckets to be turned 180° for front excavators. For this type of quick-coupler it's no need for manual adjustment.

The hook coupler should be manual adjusted for best fitting.

It is the same price for mechanical and hydraulic quick-couplers for excavators.

Article no	Machine weight	Coupler type	Specification
059...	1-3 ton	S 35 [ABL 05]	180- grind [end.mek]
109...	2-7 ton	S 40 [ABL 10]	200-grind
149...	7-12 ton	S 45 [ABL 14, B-12]	290-grind
169...	9-14 ton	S 50 [ABL 16, S-5, B 14]	270-grind
179...	10-17 ton	S 60 [ABL 17, S-6, B 16]	340-grind
179...HD	15-17 ton	S 60 [ABL 17HD, S-6, B 16]	340-grind heavy duty
209...	16-24 ton	S 1 [ABL 20, B-20]	Standard
209...HD	22-24 ton	S 1 [ABL 20HD, B-20]	Heavy Duty

209...L	13-16 ton	S 1 [ABL 20L, B-20]	Light
219...	16-24 ton	S 70 [ABL 21]	452-grind
279...	24-29 ton	S 2 [ABL 27A/B, B-27]	Standard
279...HD	29-33 ton	S 2 [ABL 27A/B, B-27]	Heavy Duty
289...	24-29 ton	S 80 [ABL 28]	592-grind
309...	30-45 ton	S 3 [ABL 30, B-30]	Standard
309...HD	41-45 ton	S 3 [ABL 30HD, B-30]	Heavy Duty
309...L	30-34 ton	S 3 [ABL 30L, B-30]	Light
399...	30-45 ton	S100 [ABL 39]	750-grind
459...	45-90 ton	ABL 45	Standard
959...	90-180 ton	ABL 95	Standard

Other dimensions on request: +46 [0] 382 676 00 info@abl.se

ABL Box 200 576 24 SÄVSJÖ SWEDEN Tel +46 (0) 382 676 00 Fax +46 (0) 382 615 20 info@abl.se www.abl.se